



If preamplifier is not used, the elements Q3, R5, R6, R7, D3, SW2 are not needed

- L1 - 2 t; $\phi=1.2$ mm; D= 8 mm; L=6 mm
- L2 - 0,5 t; $\phi=3,0$ mm; D= 25 mm
- L3 - 6,5 t; $\phi=1,5$ mm; D= 7 mm; L= 14 mm
- L4 - 8 t; $\phi=1,5$ mm; D= 7 mm L= 15 mm
- L5 - 6,5 t; $\phi=1,5$ mm; D= 7 mm; L= 14 mm
- Dr1 - 6 t; $\phi=0,8$ mm; K 7x4x2
- Dr2 - 4t; $\phi=2$ mm; D= 8 mm; L=12 mm
- Dr3 - 2 t; $\phi=1,0$ mm; ДВУЦЕВКА

POWER AMPLIFEIR 100 W FOR 144 MHZ
LZZZK